

Throttle valve sensor

Throttle valve sensors are attached to the throttle valve axle. They capture the opening angle of the throttle valve and forward this information to the engine control unit as an electrical signal. The engine...

Bilder

Hersteller

HITACHI
Inspire the Next

Hitachi



Pierburg

PIERBURG

Valeo

Valeo_EN



ATE

Quelle:

<http://www.my-cardictionary.comhttps://www.my-cardictionary.com/cardictionary/hybrid/products/throttle-valve-sensor.html>